


# Simplified installation schematics for water-jacket fireplace inserts LB 800PW and LB 810PW



**Red** feed water  
**Blue** return water

1. Sewage outflow
2. Return-water spigot
3. Container
4. Safety valve
5. Fresh water supply
6. Safety valve spigot
7. Hot water outlet spigot
8. Temperature sensor
9. Discharge spigot
10. Circulation pumps
11. Controller
12. Electric, gas stove Exchanger
13. Exchanger

**ATTENTION:**  
 The insert can be left- or right-side connected.  
 Unused spigots must be closed